



INSTALLATION

INSTALLATION WITH REMOTE LED DRIVER INSTALLAZIONE CON DRIVER REMOTO

H. MIN
Symmetric:
50 mm



H. MIN
Asymmetric:
35 mm




- 1 Make a hole in the plasterboard.
Fare un foro nel cartongesso.


Ø40 mm




- 2 Insert the housing box in the hole.
Inserire la controcassa nel foro.




- 3 Fix the housing box to the plasterboard by using self-threading screws. Make sure the head of the screws being completely within the plasterboard.
Fissare la controcassa al cartongesso utilizzando le viti autofillettanti.
Accertarsi che tutta la testa della vite sia all'interno del cartongesso.



- 4 Plaster and sand.
Stuccare e carteggiare.



- 5 Paint.
Dipingere.



- 6 Clean the inside of the housing box.
Pulire l'interno della controcassa.

